



1. PRODUCT DESCRIPTION

The DERBLAUE® Complete Set is a comprehensive liquid collection system that has been specially developed for professional use in sanitary, heating and air conditioning technology (HVAC). It enables the clean collection and efficient pumping out of liquids during maintenance and installation work. The Set consists of a flexible Professional Tub, a powerful Pumping System, a Slide and Single- and Double-Splash-Guard.

[DERBLAUE®](#)

2. SCOPE OF DELIVERY

- **Professional Tub:** Made from special fabric-reinforced tarpaulin with integrated bending metal elements.
 - **Pump system:** Powerful Pump with a flow rate of 10 liters per minute, including Hose and Mounting Clip.
 - **Power Supply Unit:** For operating the Pump or charging the Battery.
 - **Battery:** 6000 mAh shock- and splash-proof ion Battery with 3.5 hours running time and up to 1,500 liters of flow rate.
 - **Slide:** With Suspension System, strong neodymium magnets and eyelets; 30 cm wide at the top, 20 cm at the bottom, 50 cm long, with integrated bending metal elements.
 - **Single-Splash-Guard:** With 22 mm opening and integrated bending metal elements.
 - **Double-Splash-Guard:** Two openings each 15 mm apart at 50 mm intervals, with integrated bending metal elements.
 - **bag:** Practical bag for storing and transporting the set.
-

3. TECHNICAL DATA

- **Professional Tub:**
 - **Material:** Fabric-reinforced special tarpaulin
 - **Capacity:** 10 liters
 - **Dimensions:** 34 cm x 34 cm x 12.5 cm
 - **Weight:** 580 g
- **Pump:**
 - **Flow rate:** 10 l/min
 - **Operating time with Battery:** 3.5 hours
 - **Maximum flow rate per Battery charge:** 1,500 L

- **Battery:**
 - **Capacity:** 6,000 mAh
 - Protection class:** Shock and splash-proof
 - **Slide:**
 - **Dimensions:** 30 cm wide at the top, 20 cm wide at the bottom, length 50 cm
 - **Fastening:** Neodymium magnets and eyelets
 - **Single-Splash-Guard:**
 - **Opening:** 22 mm
 - **Double-Splash-Guard:**
 - **Openings:** Two openings 15 mm each, 50 mm apart
-

4. SAFETY INFORMATION

- **Use:** The set is suitable for collecting and pumping non-aggressive liquids.
 - **Handling:** Avoid contact of the components with sharp or pointed objects to prevent damage.
 - **Storage:** Clean the parts after use and store them in a dry place to ensure the longevity of the material.
 - **Electrical safety:** Observe the safety guidelines for operating the Pump with a mains adapter or Battery.
 - **Warning:** Not suitable for drinking water. This product is intended exclusively for non-potable liquids. Use in drinking water systems may impair water quality.
-

5. LABELING AND TRACEABILITY

- **Manufacturer:** Aqua Evolution Systems GmbH
 - **Brand:** DERBLAUE®
 - **Product name:** Complete Set
 - **Item number:** 13014
 - **Contact address:** Aqua Evolution Systems GmbH, Lindenstr. 14, 87477 Sulzberg Germany
 - **Website:** store.derblaue.com
-

6. OPERATING INSTRUCTIONS

Assembly and use of the DERBLAUE® Complete Set

1. **Prepare the Professional Tub:**
 - Unfold the Professional Tub and shape it according to the operating environment using the bending metal elements.
 - Position the Professional Tub under the area to be serviced to collect liquids.

2. **Put the Pump into operation:**
 - o Connect the hose to the Pump and attach the Mounting Clip to a suitable location.
 - o Operate the Pump using either the mains adapter or the charged Battery.
 - o Switch on the Pump to pump out the collected liquid.
 3. **Use of Slide and splash guards:**
 - o Attach the Slide using the neodymium magnets and eyelets to direct liquids into the sump.
 - o Place the Single- or Double-Splash-Guard around pipes to act as a splash guard.
 4. **After use:**
 - o Turn off the Pump and disconnect it from the power source.
 - o Empty and clean the Professional Tub and Slide with clean water and a mild detergent.
 - o Allow all components to dry completely.
 - o Fold up the Professional Tub and store the entire Set in the bag provided.
-

7. RISK ANALYSIS

- **Mechanical risks:**
 - o Possible damage due to improper handling (e.g. by sharp or pointed objects).
 - o **Measures:** Careful handling and avoid contact with sharp objects.
 - **Electrical risks:**

Hazards due to improper use of the Power Supply Unit or Battery.

 - o **Measures:** Use the Power Supply Unit supplied and observe the safety guidelines for Battery operation.
 - **Chemical risks:**
 - o Possible material damage due to aggressive chemicals.
 - o **Measures:** Only use the components with recommended liquids.
 - **Slip hazard:**
 - o Escaping liquids can make the work area slippery.
 - o **Measures:** Ensure that the collected liquid is removed in good time.
-


8. DECLARATION OF CONFORMITY

Manufacturer:

Aqua Evolution Systems GmbH
Lindenstr. 14| 87477 Sulzberg| Germany

Aqua Evolution Systems GmbH hereby declares that the DERBLAUE® Complete Set complies with the requirements of EU Regulation 2023/988 on general product safety (GPSR).

Date: 12.12.2024

Signature: 

Position: CEO

9. CLEANING AND CARE

Clean all components of the Complete Set (e.g. Professional Tubs, Funnels, Slides, Carrying Bags) after each use with warm water and a mild detergent. Dry all parts completely before folding or storing them. Store the Complete Set in a dry, cool place and protect it from direct sunlight and aggressive chemicals.

10. MAINTENANCE AND INSPECTION

Before each use, check all bending metal elements and Suspension Systems for deformation; carefully straighten them if necessary. Check the materials regularly for cracks, signs of wear or damage to seams and magnets. Replace damaged components immediately to ensure the functionality and safety of the Complete Set.

11. DISPOSAL

- **Environmentally friendly disposal:**
 - Dispose of defective or no longer required components of the set in accordance with local regulations.
 - Plastic and metal parts can be recycled.
 - Electronic components such as the Battery and Power Supply Unit must not be disposed of with household waste. Contact a suitable recycling center.

12. WARRANTY AND CONTACT

For warranty inquiries or further information, please contact: DERBLAUE® Customer Service

by e-mail: service@derblaue.com

Phone: +49 8376 3269961