



1. PRODUCT DESCRIPTION

The DERBLAUE® Helper Set was developed to leave construction sites efficient and clean by allowing liquids to be directed into a separately available Professional Tub in a controlled manner, even from difficult installation situations. All components have highly flexible bending metal elements that allow perfect adaptation to different surfaces. The Slide is also equipped with strong neodymium magnets that allow it to be connected to the bent metal elements of the Professional Tub or splash guards.

[DERBLAUE®](#)

2. SCOPE OF DELIVERY

- **Slide:** With hanging lugs, strong neodymium magnets and eyelets; 30 cm wide at the top, 20 cm at the bottom, 50 cm long; integrated bending metal elements.
 - **Single-Splash-Guard:** With 22 mm opening; integrated bending metal elements.
 - **Double-Splash-Guard:** With two 15 mm openings, 50 mm apart; integrated bending metal elements.
-

3. TECHNICAL DATA

- **Slide:**
 - **Width top:** 30 cm
 - **Bottom width:** 20 cm
 - **Length:** 50 cm
 - **Attachment:** Hanging lugs with neodymium magnets and eyelets
 - **Single-Splash-Guard:**
 - **Opening:** 22 mm
 - **Double-Splash-Guard:**
 - **Openings:** Two 15 mm each
 - **Distance between the openings:** 50 mm
-

4. SAFETY INFORMATION

- **Application:** Suitable for conducting common fluids such as contaminated heating water, fluids containing glycol, hydraulic and heating oil.
 - **Handling:** Avoid contact of the components with sharp or pointed objects to prevent damage.
 - **Storage:** Clean the parts after use and store them in a dry place to ensure the longevity of the material.
 - **Fastening:** Ensure that the neodymium magnets adhere firmly to metallic surfaces or the bending metal elements of the Professional Tub or splash guards.
 - **Warning:** Not suitable for drinking water. This product is intended exclusively for non-potable liquids. Use in drinking water systems may impair water quality.
-

5. LABELING AND TRACEABILITY

- **Manufacturer:** Aqua Evolution Systems GmbH
 - **Brand:** DERBLAUE®
 - **Product name:** Helper Set
 - **Item number:** 13003
 - **Contact address:** Aqua Evolution Systems GmbH Lindenstr. 14 | 87477 Sulzberg | Germany
 - **Website:** store.derblaue.com
-

6. OPERATING INSTRUCTIONS

1. **Attach the Slide:**
 - o Attach the Slide to metallic surfaces using the neodymium magnets or combine it with the bending metal elements of the Professional Tub or splash guard.
 - o Use the integrated bending metal elements to adapt the shape of the Slide to the local conditions in order to guide liquids in a targeted manner.
2. **Use a Single-Splash-Guard:**
 - o Place the Single-Splash-Guard around pipes with a diameter of 21-26 mm to act as a splash guard.
 - o Combine the splash guard with the Slide to drain liquids in a controlled manner.
3. **Insert Double-Splash-Guard:**
 - o Use the Double-Splash-Guard for pipes with two 15 mm openings that are 50 mm apart.
 - o This can also be combined with the slide to drain liquids in a targeted manner.
4. **After use:**
 - o Clean all components with clear water and a mild detergent.
 - o Allow the parts to dry completely before storing them.

7. RISK ANALYSIS

- **Mechanical risks:**
 - Possible damage due to improper handling or sharp objects.
 - **Measures:** Careful handling and avoid contact with sharp objects.
- **Chemical risks:**
 - Possible material damage due to aggressive chemicals.
 - **Measures:** Only use the components with recommended fluids.
- **Fastening risks:**
 - Improper fastening can cause the Slide to slip.
 - **Measures:** Ensure that the neodymium magnets are firmly attached and that the Slide is in a stable position.

8. DECLARATION OF CONFORMITY

Manufacturer:

Aqua Evolution Systems GmbH
Lindenstr. 14| 87477 Sulzberg| Germany

Aqua Evolution Systems GmbH hereby declares that the DERBLAUE® Helper Set complies with the requirements of EU Regulation 2023/988 on general product safety (GPSR).

Date: 12.12.2024

Signature: 
Position: CEO

9. CLEANING AND CARE

Clean all parts of the Helper Set, such as small collecting aids, Funnels or Professional Tubs, after each use with warm water and a mild detergent. Dry all components completely before folding or storing them.
Store the Helper Set in a dry, cool place and protect it from direct sunlight and aggressive chemicals.

10. MAINTENANCE AND INSPECTION

Before each use, check the bending metal elements or flexible edges of the products for deformation and carefully straighten them if necessary.

Regularly check all materials and seams for cracks, signs of wear or other damage.

Replace damaged parts immediately to ensure safe and reliable use of the Helper Set.

11. DISPOSAL

- **Dispose of in an environmentally friendly manner:**
 - o Dispose of defective components of the set in accordance with local regulations.
 - o Plastic and metal parts can be recycled.
 - o Electronic components or parts with integrated magnets must not be disposed of with household waste; take them to a suitable recycling center.
-

12. WARRANTY AND CONTACT

For warranty inquiries or further information, please contact: DERBLAUE® Customer Service

by e-mail: service@derblaue.com

Phone: +49 8376 3269961